



INSTALLATION

Panel Mount Installation



Installation in 5 easy steps

Obex Panel Extenders take less than 5 minutes to install. The only tool required is an allen wrench that we provide. Our cubicle extenders are equipped with universal adjustable brackets. Our standard adjustable bracket fits panels from 1.5" thick to 3" thick and our large adjustable bracket fits panels from 3" to 3.75" thick.

Desk Mount Installation



Installation in 4 easy steps

Obex Desk Mount Panels take less than 5 minutes to install. The only tool required is an allen wrench that we provide. Simply Install clamp around edge of desk and tighten thumb screw on the bottom of the bracket. Then set the tile in the upper channel and tighten the set screw with the provided allen wrench.

Shipped on request, Rubber strip to fill small gap on bottom of tile

