

Desk Mount Installation Instructions

Desk Edge Installation



Step 1

Attach the clamp brackets to the desk mount bracket with the two screws provided in the designated holes.



Step 2

Attach the assembled brackets to the desk edge using the thumb screw.



Step 3

Place the screen in between the mouth of the clamp bracket and tighten down using the provided bolt.



Part list:

- (2) DeskMount Brackets
- (2) Clamp Brackets
- (4) Screws
- (2) Bolts

Front to Back Installation



Step 1

Attach the clamp brackets to the desk mount bracket with the two screws provided in the designated holes.



Step 2

Attach the assembled brackets to the front and back of the desk using the thumb screw.



Step 3

Place the screen in between the mouth of the clamp bracket and tighten down using the provided bolt.