OBEX Cubicle Door

Installation Guide



1 Open the mouth of the bracket around the existing cubicle wall at the height of the bottom rail of the cubicle door. Apply pressure to the bracket sides and tighten the set screw until the bracket is snug around the cubicle wall.



2 Place the bottom rail of the cubicle door over the U-channel on the bottom bracket. The rail should rest slightly off the bottom of the U-channel to assure smooth sliding.



3 Loosely attach the top bracket onto the existing cubicle wall. Slide the bracket down until it’s U-channel is covering the top rail of the cubicle door. Leave a small gap between the rail and the u-channel top to assure smooth sliding. Apply pressure to the bracket sides and tighten the set screw until the bracket is snug around the cubicle wall.



4 Cover the screw heads with the provided cap screws.

OBEX Cubicle Door

Installation Guide

